

SIGMA S6500 UI Module



User's Manual

Revision: 31.08.2006

Firmware: 050210

SELCO A/S
Betonvej 10 - DK-4000 Roskilde
Denmark
Phone: 45 7026 1122 - Fax: 45 7026 2522
e-mail: selco.dk@selco.com
Web site: www.selco.com

Table of Contents

1	Preface.....	3
2	System Preparation	4
2.1	Setting the CAN bus address	4
3	Installation.....	5
3.1	Dimensions	6
4	Terminals	7
4.1	Power Supply	8
4.1.1	Primary Supply	8
4.1.2	Backup Supply	8
4.2	CAN BUS	8
4.3	Alarm	8
4.4	I/O	8
5	Specifications	9

1 Preface

The SELCO Sigma S6500 UI module can be used to configure the SELCO Sigma S6000 IO/P and S/LS modules. The UI module will access the configuration parameters stored in the IO/P and S/LS module and present these parameters to the operator in a user-friendly and easy accessible menu structure. Furthermore the UI module functions as a digital multi-meter, providing information about voltages, currents, load levels, power factor etc.

2 System Preparation

2.1 Setting the CAN bus address

The 4-point dip-switch located on the rear side of the S6500 is used to set the CAN bus address of the module. The CAN bus address is set as a binary value by 4 ON/OFF switches. Valid CAN bus address are 1 to 15.

The S6500 can be set to any address in the range 1 to 15, however it's typically most practical to set it to number 1.

The binary system works on the principle described below.

- Switch 1 represents the decimal value 1
- Switch 2 represents the decimal value 2
- Switch 3 represents the decimal value 4
- Switch 4 represents the decimal value 8

As an example, the address 1 is assigned by setting switch 1 to ON and the remaining switches to OFF. Address 10 is assigned by setting switch 2 and 4 to ON and switch 1 and 3 to OFF. The decimal value corresponds to the sum of the values ON switch values.

3 Installation

The S6500 is designed for flush mounting. Outside dimensions are H x W x D = 144 x 144 x 70mm. A cut out with dimensions H x W = 138 x 138mm must be made in order to install the unit in the switchboard cabinet.

Make sure that there is enough space in the switch board cabinet behind the unit to install the plug-in connectors and the cables. An installation depth of between 50 and 70mm is recommended.

The S6500 is secured to the switch board plate through the use of the 4 mounting/fixing brackets included in the package.

Install the S6500 as described below.


- Find a location in the switch board cabinet with enough installation depth to house the M3000 unit. Make sure that the selected location is also satisfactory from the operator's point of view.
- Keep in mind that it may be convenient to make room for the RS232 connection if you plan to do external programming from a PC in the future.
- Make a cut out with the dimensions H x W = 138 x 138mm in the cabinet plate.
- Remove all the plug-in connectors located at the rear side of the unit.
- Make sure the rubber gasket is in place behind the unit front plate. This gasket is necessary to ensure compliance with the IP54 requirements.
- Insert the unit into the cut out.
- Place the 4 mounting/fixing brackets in the small rectangular cut outs located at the top and bottom plates of the unit.
- Tighten the 4 mounting/fixing brackets with a screwdriver until the unit is firmly seated.

Be careful not to make the connection cables too short. Extending the length of all cables with around 100mm will ease any later service task.


A twisted-pair cable must be used for the CAN bus connection. The twisted-pair cable should at least have 4 cords (twisted 2 by 2). An outer shield is also advantageous, especially if the cable is long or if the environment contains excessive levels of electro-magnetic interference. The shield can be left unconnected and is only to be used if problem occur.

Terminals 2 and 4 of the CAN connector must share one set of twisted-pair wires. The GND and connection can use one of the wires within the remaining twisted-pair set. Also note that 150 ohm termination resistors are to be attached at each end of the CAN bus cable. The termination resistors must be attached between the previously mentioned terminal sets, directly on the plug-in connector.

3.1 Dimensions



4 Terminals



4.1 Power Supply

The module is equipped with two separate power supplies. Each supply works on a nominal voltage of +24 VDC. The primary supply is fully isolated from the backup supply and vice versa. Both supplies are isolated from the remaining circuit of the module. The dual power supply system is provided for safety reasons and true redundancy is only obtained if each supply is powered by an independent source. The module is capable of operating on either one of the two supplies; however loss or failure of either the primary or the backup supply will cause the alarm relay to de-energize.

4.1.1 Primary Supply

The primary power source (e.g. the switch board +24 VDC supply) connects to terminal 1 and 2. Terminal 1 is positive and terminal 2 is the negative reference of the primary supply. The negative reference is not connected to the common reference of the module (GND), as this would disrupt the isolation of the supply circuitry. The LED marked *PRIMARY SUPPLY* will illuminate green (steady light) when the supply source is live and the voltage level is within limits.

4.1.2 Backup Supply

The backup power source (e.g. a +24 VDC battery backup) connects to terminal 3 and 4. Terminal 3 is positive and terminal 4 is the negative reference of the backup supply. The negative reference is not connected to the common reference of the module (GND), as this would disrupt the isolation of the supply circuitry. The LED marked *BACKUP SUPPLY* will illuminate green (steady light) when the supply source is live and the voltage level is within limits.

4.2 CAN BUS

The CAN bus is used for high speed communication of measured and calculated parameters between all IO/P, S/LS and UI modules within the system. Only terminal 1, 2 and 4 are used. Connection of the GND connection on terminal 1 is required. Terminal 1 is connected to the common reference of the module (GND). Data signal CAN L (Low) of the CAN bus interface connects to terminal 2, while CAN H (High) connects to terminal 4. A termination resistor of 150 ohm must be connected between CAN L and CAN H (terminal 2 and 4) at each end of the cable. Wires for CAN L and CAN H must be twisted (twisted-pair).

4.3 Alarm

The Relay Contacts plug-in connector includes an alarm change-over relay. The alarm relay occupies terminal 1, 2 and 3. For safety reasons, the alarm relay is always normally energized. This is to ensure that e.g. an external siren is activated if the module loses both supplies (requires that the siren is powered from a totally independent source). The relay contact connects terminal 2 and 3 when energized and terminal 2 and 1 when de-energized. The *ALARM* LED ignites (at steady light) when the module does not operate as intended.

4.4 I/O

The I/O signals are reserved for later use.

5 Specifications

Primary Supply:	+24 V DC (-30 % / +30 %) Isolated
Backup Supply:	+24 V DC (-30 % / +30 %) Isolated
Display:	4 x 20 Characters (backlit)
Dimming:	LEDs and Display backlit 5 steps by depressing TEST button or by RS232 command
CAN Bus	
Connection	Screw terminals, 2-wire with GND (limp back function)
Protocol:	CANOpen derivative
RS232	
Connection:	Customized plug, 4-wire (non-isolated)
Function:	Configuration, Debugging or firmware update
Protocol:	ANSI terminal
Baud rate:	1200, 2400, 4800, 9600 or 19200 baud
Parity:	None, even or odd
Data bits:	7 or 8
Stop bits:	1 or 2
EMC / EMI tests:	EN 50081-2:1993 (Generic: Residential, commercial & light industry) EN 50263:1999 (Product: Measuring relays and protection equipment)
Marine tests:	EN 60945:1997 (Marine: Navigation and radio comm. equipment and systems) IACS E10:1997 (IACS unified environmental test specification)
Connections:	Plug-in screw terminals (spring terminals available as option)
Dust and Water protection:	IP54 at front
Dimensions:	144 x 144 x 35 mm (H x W x D) cut out 138 x 138 mm.
Weight:	850 g
Fixation:	Flush mount (4 mounting brackets)

The specifications are subject to change without notice.